

Instant Wireless® Series

Network Access Point

Model No.: WAP11

After physically installing the Instant Wireless® Network Access Point on your network, follow these instructions to install the USB drivers. *The USB drivers are for customers who plan to set up and use the Network Access Point through the USB port. See the User Guide for details.*

Installing USB Drivers for the Instant Wireless® Network Access Point for Windows Millennium

Note: Do not click **Cancel** or **Skip** at any time during the installation. Doing so will prevent your driver from being properly installed on your PC.

1. Once the Wireless Network Access Point is connected to the PC, Windows Millennium will automatically identify and prompt you to install the necessary driver. *(When you insert the Setup Utility CD, the installation may try to run automatically. If it does, exit out of the program and return here.)*



2. Select **Automatic Search for a better driver (Recommended)** and click the **Next** button. This will search for the Windows Millennium driver. If Windows asks for the file **Brigddfu.inf**, direct the installation to **D:\wap11\usbdrv** (where D: is the letter of your CD-ROM drive).



Quick Installation

for Windows Millennium

This sheet will guide you through the basic steps needed to install this Linksys product in your PC. If you have any problems during installation, see the **Troubleshooting** section in the **User Guide**.

3. Windows will now install the driver files. Click the **Finish** button when completed.



In order to complete the entire installation and configuration process for the Wireless Access Point, follow the instructions for the USB Configuration Utility (or for the SNMP Utility if you do not have a USB port) described in the User Guide.