

**Instant Gigabit Series**

**Instant Gigabit Network Adapter**

Model No.: EG1032  
EG1064

# Quick Installation

## for Windows 98

This sheet will guide you through the basic steps needed to install the Instant Gigabit Network Adapter onto your network. If you have any problems during installation, refer to the **Troubleshooting** section of the **User Guide**.

### Overview

After installing the Instant Gigabit hardware in your PC, follow these instructions to install the adapter driver. If you experience any difficulty, refer to your User Guide for more information.

**Note:** Do not click **Cancel** or **Skip** at any time during the installation. Doing so will prevent the driver from being properly installed on your PC.

### Installing Your Instant Gigabit Network Adapter Drivers

1. **Start up your PC.**
2. **Windows 98 will automatically detect** the presence of the PCI Ethernet Controller hardware in your computer.
3. Insert the *Instant Gigabit Network Adapter Driver Disk* into your floppy drive while the *Add New Hardware Wizard* window is visible. Click **Next**.



4. Select **Search for the best driver for your device (Recommended)**. Click **Next**.
5. Select **Specify a location** and enter **a:\win98** in the drop down box. Click **Next** to continue.




6. A window will open saying that Windows is now ready to install the *Linksys EG1032/EG1064 Instant Gigabit Network Adapter* driver. Click **Next**.



7. Windows will begin copying the Instant Gigabit Network Adapter's driver files to your PC.

At this point, the installation may require files from your Windows 98 CD-ROM. If prompted, insert your Windows 98 CD-ROM into your CD-ROM drive and enter **d:\win98** in the box that appears (where "d" is the letter of your CD-ROM drive). If you were not supplied with a Windows 98 CD-ROM, your Windows files may have been placed on your hard drive by your computer manufacturer. While the location of these files may vary, many manufacturers use **c:\windows\options\cabs** as the path. Try entering this path into the box. If no files are found, check your computer's documentation or contact your computer manufacturer for more information.

8. Once the driver is installed, the **Advanced Settings** screen will appear. The default settings should allow the Adapter to function properly. Click the **OK** button to continue. For more information about these settings, refer to the **Advanced Settings** section of the User Guide.
9. When asked if you want to restart your PC, remove all disks and click **Yes**. If Windows does not ask you to restart your PC, click the **Start** button, choose **Shut Down**, choose **Restart**, then click **Yes**.



The Windows 98 driver installation is complete. Refer to the section on *Configuring the Instant Gigabit Network Adapter for Windows 95, 98, and Millennium* for more information about the setup of the Adapter.